



WITTENBERG 9100

Weekly Cleaning Quick Reference Guide - Replace Mixing Bowls & Powder Traps

1. Prepare for Cleaning

Remove Canisters

- a. After opening door, touch X on keypad. Then, remove soluble canisters by using handle and lifting out of machine.
- b. Hang canisters on inside of door. Canisters can also be placed on a flat, clean surface.



2. Uninstall Parts

Disconnect Hoses & Bowls


- a. Disconnect blue tubes from mixing bowls.
- b. For each mixing bowl, turn green ring counterclockwise about 1/8 turn.



3. Remove Parts

Remove Mixers & Powder Traps

- a. Firmly pull mixing bowl forward to remove from machine.
- b. Remove powder traps.



4. Clean Parts

Clean Mixing Bowls & Replace Powder Trap

- a. Wash mixing bowls with warm water and soft cleanser or dish soap. Dry with paper towel.
- b. Reattach round cap to mixing bowls. Then, replace powder traps.

5. Reinstall Parts

Install Mixers & Reconnect Tubes

- a. Position and align parts on mixing bowls to matching parts in machine. Next, turn green ring clockwise to lock in place.
- b. Reconnect blue tubes to mixing bowls.



6. Clean Interior

Clean Black Tray and Inside Door

- a. Remove grounds container (waste bucket) and wipe tray with dry cloth.
- b. Clean lower part of machine and inside of door.

7. Replace Other Parts

Reinstall Waste Bucket & Drip Tray

- a. Return waste bucket to machine.
- b. Reattach drip tray assembly to bottom and close door.

8. Complete Fast Actions

Waste Bucket & Rinse Tasks

- a. Touch icon in lower left corner to display actions.
- b. Touch waste bucket question. Allow machine to finish cycle. Touch icon in lower left screen. Touch rinse machine question. Allow machine to finish cycle and then touch exit.

NOTE: Wipe cup area with cloth and soft cleanser after completing *Fast Actions* tasks.